

Drawn from a pair of ENX Articles written by The Parts Drop...

**Introducing: Xerox C118 / M118... Scratching the Surface. (PART I)** Introduction & Status Code Meanings for the Xerox CopyCentre C118, & WorkCentre M118, M118i.



These machines are still being placed today by Authorized Dealerships nationwide... they're selling strong and I suspect for good reason. These models were released originally in 2004 but new ones are still available from Xerox. I thought at first that the machines were Fuji Xerox engines, but now that I've seen how the diagnostics work... I have my doubts. The logic is different from the usual (it reminds me more of the Toshiba equivalent machines Xerox has sold in the past). So far I'm not aware of any crossovers to other makes. Folks are telling me that these are machines they want to support... so let's get started.

Physically, they are very closely related to the C123/128/133, M123/128/133, & Pro123/128/133... also the Phaser 5500, however, the Status Codes and Diagnostics are surprisingly very different between the two groups of models. This article will focus on the C118 style and we'll hit on the C123 style in a future article.

These machines are rated to handle a volume of up to 50K pages per month and they run 18 pages per minute. They range from \$1348.- for the stripped down version of the C118 to \$3249.- for a loaded M118i.

The Toner Cartridges have a stated yield of 11K prints... They sell under the Reorder # 6R1179 for around \$75.- per cartridge. The C123/128/133 cartridges look the same, but they yield 30K, and sell for \$155.- (6R1184). No doubt the "CRUM"(Customer Replaceable Unit Monitor) chip has a different ID, so the machine can tell if you put the wrong one in there.

This machine uses a new type of CRUM... instead of using Connectors, it uses a radio feedback chip which makes no physical connection at all. I can't help but call it the "Star Wars" chip because it reminds me of the Star Wars figures which came out a few years ago. Those toys had a similar technology. The figures came with chips, and then there was an electronic toy sold which could tell which chip was placed on it and it'd play back sound clips relating to the character the chip belonged to. They take it a step further in the copiers though... the machine can write to the chip as well as being able to read it.

They have come up with a new name for the Drum Cartridges this time around... the Service Manual refer to them as "Xero/Developer Cartridges". They have a yield of 60K and retail for \$199.- (13R589). The C123/128/133 machines use the same cartridge as the C118 / M118. Like the Toner Cartridges, these Drum Cartridges also use the new 'Star Wars' type of CRUM chip.

The Fuser is supposed to run for around 175K, although I'm told many of them require work or replacement considerably before the count runs out. According to the parts list I have here, none of the fuser parts are spared... so you have to replace the whole darned thing even if it's just a gear which needs replacing. That'll remain true for a little while... until someone goes and makes some good aftermarket parts for repairing the fusers.

The Status Codes at first glance looked different from other Xerox models I'm familiar with... In the Service Manual, they are a letter followed by one number, then a dash followed by 4 digits. Looking more closely, I can see that if you drop the last three '0's in the subcode, the codes follow a familiar pattern after all (U4-1 for example instead of "U4-1000"). I suspect that the machine may actually display only the first digit of the subcode on display. So... the machine may actually show "C1-3" instead of "C1-3000". The code meanings stays consistent with older models: The Status Codes which start with "C" are still paper jam related and the J1 is for the toner, and U4 is for fuser problems... Sound familiar?

Here's a list of the Status Codes and roughly what they mean. There are a bunch of Fax related codes which we won't cover here since the list is kind of long for this article.

<b>Status Code</b>	<b>Description</b>
C1-3000 (C1-3)	Paper Jam before Registration Sensor. (when feeding from Tray 1)
C2-2000 (C2-2)	Paper Misfeed before Tray 2 Feed Sensor.
C2-3000 (C2-3)	Paper Jam before Registration Sensor. (when feeding from Tray 2)
C3-1000 (C3-1)	Paper Misfeed before Tray 3 Feed Sensor.
C3-3000 (C3-3)	Paper Jam before Registration Sensor. (when feeding from Tray 2)
C4-0000 (C4-0)	Paper Misfeed before Tray 4 Feed Sensor.
C4-1000 (C4-1)	Paper Jam before Tray 3 Feed / Vertical Transport Sensor. (when feeding from Tray 4)
C4-2000 (C4-2)	Paper Jam before Tray 2 Feed / Vertical Transport Sensor. (when feeding from Tray 4)
C4-3000 (C4-3)	Paper Jam before Registration Sensor. (when feeding from Tray 4)
C6-1000 (C6-1)	Paper Jam before Registration Sensor. (when feeding from Duplex)
C6-2000 (C6-2)	Paper Jam before Registration Sensor. (when feeding from Duplex... non-stop)
C8-2000 (C8-2)	Paper Jam... Tray 2 Feed / Vertical Transport Sensor did not deactuate.
C8-3000 (C8-3)	Paper Jam... Tray 3 Feed / Vertical Transport Sensor did not deactuate.
C8-4000 (C8-4)	Paper Jam... Tray 4 Feed Sensor did not deactuate.
C8-6000 (C8-6)	Paper Jam... Duplex Feed Sensor did not deactuate.
C9-3000 (C9-3)	Paper Jam... before Registration Sensor (when feeding from the Manual Bypass Tray (MPT)).
E1-1000 (E1-1)	Paper Jam... Registration Sensor did not deactuate.
E1-2000 (E1-2)	Paper Jam before Exit Sensor
E1-6000 (E1-6)	Paper Jam... Paper remains on the Registration Sensor
E3-1000 (E3-1)	Paper Jam... Fuser sensor did not deactuate in time.
E3-6000 (E3-6)	Paper Jam... Fuser sensor did not deactuate in time.
E8-2000 (E8-2)	Paper Misfeed when feeding from the Duplex.
H1-2000 (H1-2)	Tray 2 lift failure, or the Tray 2 size switch detected no tray present.
H1-3000 (H1-3)	Tray 3 lift failure, or the Tray 3 size switch detected no tray present.
H1-4000 (H1-4)	Tray 4 lift failure, or the Tray 4 size switch detected no tray present.
H2-7000 (H2-7)	Duplex Module communication failure.
H3-1000 (H3-1)	Offset Catch Tray home position failure.
H4-1000 (H4-1)	Tray 1 paper size detection problem.
H4-2000 (H4-2)	Tray 2 paper size detection problem.
H4-3000 (H4-3)	Tray 3 paper size detection problem.

H4-4000 (H4-4)	Tray 4 paper size detection problem.
H7-3000 (H7-3)	Two Tray Module (2TM) data error detected in the 2TM board.
H7-4000 (H7-4)	Two Tray Module memory read / write error.
H7-7000 (H7-7)	Two Tray Module communication error.
H7-8000 (H7-8)	Invalid tray module detected.
H8-1000 (H8-1)	Tray 1 paper size switch failed.
H8-2000 (H8-2)	Tray 2 paper size switch failed.
H8-3000 (H8-3)	Tray 3 paper size switch failed.
H8-4000 (H8-4)	Tray 4 paper size switch failed.
H9-3000 (H9-3)	Single Tray Module (STM) memory problem detected.
H9-4000 (H9-4)	Single Tray Module (STM) memory read/write problem.
H9-7000 (H9-7)	Single Tray Module (STM) communication error.
J1-2000 (J1-2)	Toner Cartridge empty.
J3-1000 (J3-1)	Xero/Developer cartridge (Drum Ctg.) not installed.
J4-1000 (J4-1)	Auto Toner Control (ATC) sensor failure.
J6-1000 (J6-1)	Xero/Developer cartridge (Drum Ctg.) end of life.
J7-1000 (J7-1)	Xero/Developer cartridge (Drum Ctg.) CRUM Chip communication failure.
J7-2000 (J7-2)	Xero/Developer cartridge (Drum Ctg.) CRUM Chip write failure.
J7-3000 (J7-3)	Xero/Developer cartridge (Drum Ctg.) CRUM Chip is invalid or the wrong type (ID failure).
J8-1000 (J8-1)	Toner Cartridge CRUM Chip communication failure.
J8-2000 (J8-2)	Toner Cartridge CRUM Chip write failure.
J8-3000 (J8-3)	Toner Cartridge CRUM Chip is invalid or the wrong type (ID failure).
S1-0000	Carriage motion problem.
S1-0001	Document Feeder top cover opened during scanning from the platen glass.
S1-0010	Document Misfeed (ADF) – The Document Feed Sensor did not see the document being fed in.
S1-0011	Document Jam (ADF) – The Document Lead Edge Sensor did not detect the document in time.
S1-0012	Document too long... or Lead Edge Sensor did not deactuate on time.
S1-0013	Document too short...
S1-0014	Document jam (ADF). Document remains on both document sensors.
S1-0015	Document platen opened during Document Feeder (ADF) scan.
S1-0016	Document Feeder top cover opened during Document Feeder (ADF) scan.
S1-0020	Document Misfeed (DADF) – The Document Feed Sensor did not see the document being fed in.
S1-0021	Document Jam (DADF) – The Document Lead Edge Sensor did not detect the document in time.
S1-0022	Document too long (DADF)... or Lead Edge Sensor did not deactuate on time.
S1-0023	Document too short... (DADF)
S1-0024	Document duplexing jam.

S1-0025	Document jam (DADF). Document remains on both document sensors.
S1-0026	Document platen opened during Document Feeder (DADF) scan.
S1-0027	Document Feeder top cover opened during Document Feeder (DADF) scan.
U0-1000 (U0-1)	Main motor failed to stop due to a control error.
U0-2000 (U0-2)	Network (ESS) image ready timed out.
U1-1000 (U1-1)	Main Motor failure.
U3-5000 (U3-5)	ROS (Raster Output Scanner or Laser Unit) Motor failure.
U4-1000 (U4-1)	Fuser failure (did not come up to temperature in time)... must be reset from diagnostics (NVM code 50-20 must be reset to '0')*.
U4-2000 (U4-2)	Fuser over temperature.... Must be reset from diagnostics (NVM code 50-19 must be reset to '0')**.
U4-3000 (U4-3)	Fuser thermistor circuit is detected as being an open circuit.
U4-9000 (U4-9)	Fuser fan failure. (the fan should be turning at power on).
U5-1000 (U5-1)	Toner dispense motor failure.
U5-2000 (U5-2)	RAM read / write failure.
U6-5000 (U6-5)	Memory failure due to low power condition.
U6-6000 (U6-6)	CRUM control ASIC has failed.
Z1-0000 (Z1-0)	Billing counter failure.

That does it for the Status Codes. We'll get into the diagnostic tests and adjustments next article. I won't leave you completely hanging though... You'll need to get into diagnostics in order to clear the Fuser Codes (U4-1 & U4-2). Here's how to do that:


**Entering Diagnostic Mode:** From the powered on state, hold down the '0' button and then press 'Start'. The display will change to opposite colors to show you it's in diagnostics. If it fails to go in at first, press the 'Clear All' button and then try it again. You can run copies from the diagnostic mode. Once you're in, there is a "Main Menu" (CE Setting), so you'll need to select the appropriate menu option (most of the stuff is in the option "Chain-Function" including component tests and memory read / write). To exit diagnostics when you're done, turn the power off and back on.

\* **Clearing the U4-1000 (U4-1) Status Code:** Enter diagnostics... Select 'Chain-Func' in the 'CE Setting' screen by using the 'Select' button, followed by 'Enter'. Select "NVRAM R/W". Enter the "Chain" (in this case '50'). Next select "Func" (function) by using the "Select" button. Enter the "function": '20' followed by 'Start'. The current value for that memory code (50-20 in this case) will appear in the "Read" column (if the machine is in a U4-1 status condition, the value will read as '1'). Change the value by pressing the "Select" button at the "Read" column to switch to "Write". Enter a '0' for the new value, and then press 'Start'. Finally, select "Write NVM".

\* **Clearing the U4-2000 (U4-2) Status Code:** Enter diagnostics... Select 'Chain-Func' in the 'CE Setting' screen by using the 'Select' button, followed by 'Enter'. Select "NVRAM R/W". Enter the "Chain" (in this case '50'). Next select "Func" (function) by using the "Select" button. Enter function '19' followed by 'Start'. The current value for that memory code (50-19 in this case) will appear in the "Read" column (if the machine is in a U4-2 status condition, the value will read as '1'). Change the value by pressing the "Select" button at the "Read" column to switch to "Write". Enter a '0' for the new value, and then press 'Start'. Finally, select "Write NVM".

Ok... that does it for this month. Next month we'll get into the diagnostic test codes and memory adjustments. Later on we'll figure out how to service the Drum Cartridge and the Fuser Module too. Happy repairs!

## **Introducing: Xerox C118 / M118... Scratching the Surface: (Part II) - Diagnostic tests & adjustments for the Xerox CopyCentre C118, & WorkCentre M118, M118i.**



Last month we took a first look at the Xerox C118 style machines. We got as far as the basics of the machine's specs and consumables, and then moved on to the meanings of the Status Codes. Now it's time to dig a little deeper and take a peek at the diagnostic tests and memory adjustments.

We'll start with a refresher from last month on how to enter Diagnostic Mode: From the powered on state, hold down the '0' button and then press 'Start'. The display will change to opposite colors to show you it's in diagnostics. If it fails to go in at first, press the 'Clear All' button and then try it again. Once you're in, the service manual says to press the "Log In/Out" button and select "System Settings". This is the highest menu and the service manual only talks about two of the choices. You can reset the Administrator Password from here if the password has been lost or changed... Choose "Changing Pass Word" followed by "Enter", you can change the Administrator Password (the default password is '1111').

From "System Settings", you can also choose "CE Settings". The CE Settings menu is basically the "Main Menu". Most of the stuff which would interest you and I, will be found in the "Chain-Function" menu including component tests and memory read / write functions. The menus within the CE Setting menu are arranged as follows:

### **CE Settings – main menu:**

- **Version** (for reading the software revision level of the machine)
- **MC. No** (for reading the serial number and product code of the machine)
- **MFC** (Includes registration and scanner adjustments, soft switches, machine configuration display, also a way to move the carriage to locking or maintenance position.)
- **Trace Dump** (for producing memory dump files)
- **Counter** (for reading print and copy counts, etc.)
- **Chain-Function** (for memory adjustments, component tests... see below for details)
- **P-ESS (Memory initialization)**

To exit diagnostics when you're done, turn the power off and back on. One positive feature is that you can run copies while still in diagnostic mode... This can be helpful when you're making copy quality adjustment since you can produce test copies without having to leave diagnostics.

Once you are in the "Chain-Function" menu, you'll see the following submenus:

### **Chain-Function – sub menu:**

- **Test Print**
- **NVRAM R/W** (Non Volatile Memory settings Read / Write)
- **A/D Check** (Some sensor reading tests such as the fuser thermistor and paper size sensors)
- **IO Check** (Input / Output component tests... for sensors, motors, solenoids, etc)
- **ATC Check** (Checks the status of the Automatic Toner Concentration sensor)

The **Memory adjustments** (NVRAM R/W) are handled by entering diagnostic mode and then selecting “CE Setting”. Use the ‘Select’ button to scroll to “Chain-Func” and then press ‘Enter’. Next enter the “Chain” which is the first part of any code (the part before the dash. For example: for the code 50-20, the number “50” would be the Chain). Then use the “Select” button to find the function you wish to change (“20” in the current example of 50-20). Enter “Func No.” then press ‘Start’ and the current value will show up in the “Read” column. Press the ‘Select’ button at the “Read” column to switch to “Write”. To change a value, enter a new value in the “Write” column and press the “Start” button. This will move the old value up. Select “Write NVM”. If the new value is within the acceptable range, the system will write the new value into memory.

Following are a bunch of the more useful sounding Memory Adjustments which are available. Many have been left out since it didn’t seem likely that they’d be useful in the course of regular field service. I must warn you, the explanations in the Service Manual of the codes are virtually non-existent, so that even out of the ones I list here, I’m not sure how you’d use them in a productive way. For example they say “normal” vs. “abnormal” for things like toner sensing (does the condition “normal” mean yes toner is sensed?... I’d assume so, but the manual isn’t saying). I also went through the troubleshooting section of the Service Manual and found very few references to actually using these codes in the procedures, so I couldn’t draw any conclusions from there.

Here’s a list for what its worth:

Chain-Func	Name	Values (range)	default value	Remarks
6-52	Image Area	0-1	0	0=Normal image area, 1=Wide image area
6-57	Lead Edge Erase offset value	0-99	0	0.135mm increments
6-58	Trail Edge Erase offset value	0-99	0	0.135mm increments
6-59	Side Edge Erase	0-16	8	0.254mm increments, 8=2.025mm
6-60	Lead Edge Nominal Erase	0-30	15	0.135mm increments
6-63	Trail Edge Nominal Erase	0-30	15	0.135mm increments
16-33	ATC Setpoint (Auto Toner Concentration)	0-99	55	
20-1	Lead Edge Registration (All Trays)	0-66	33	A higher number means the image will start later on the page. The range allows nearly 9mm total adjustment range.
23-20	Simplex / Duplex	0-1	0	0 = Simplex, 1 = Duplex
23-21	Feed Tray	1 to 6	1	1 =Tray1, 2 =Tray 2, 3 =Tray 3, 4 =Tray 4, 5 =HCF (High Cap Feeder), 6 =MPT (Manual Paper Tray)
23-23	Test Printout Choices	1-4	1	For setting which test pattern will print out from "Test Print" in the "Chain-Function" menu: 1=Stripe, 2= Dark Dusting, 3=Blank, 4=Grid

23-24	Image Area	0-1	0	0=Normal image area, 1=Wide image area, its not clear how this code is different from code 6-52.
27-52	Toner empty (for CRUM read)	0-1	0	0 = Toner ctg not empty, 1 = Toner ctg is empty.
31-2	Return Normal CRU Mode	0-1	0	CRU=Customer Replaceable Unit (drum ctg.)
42-10	Toner empty (actual toner sensing)	0-1	0	0 = "Normal", 1 = "Abnormal"
42-14	Toner Dispense Rate (10mg/s)	0-254	20	
42-15	Toner Empty State (NVM, 0 to 3)	0-4	0	
42-26	Current Humidity (%)	0-99	-	Percentage
42-3	ATC Judge (Automatic Toner Concentration)	0-1	0	0 = "Normal", 1 = "Abnormal"
42-4	Humidity sensor Judge	0-1	-	no details given in the service manual...?
42-44	Current Temperature	0-99	-	Degrees Celcius
42-5	Temperature Sensor Judge	0-1	-	This sensor is in the machine's body, not in the fuser.
43-11	Result of ATC check judgementg	0-4	-	0=Low, 1=Normal, 2=High, 3=Fail, 4=Abnormal End
50-14	Condensation detection	0-1	1	0 = Non-condensation mode, 1 = Condensation mode
50-15	Enable OCT & Inverter	0-2	1	0= disable, 1 = Inverter + OCT (Oscillating Catch Tray), 2 = Inverter only
50-20	FSR Reset Fuser Over Temp	0-99	0	0 = reset, 1 = FS1 detectes over temp., 2 = FS2 detects over temp. 3 = On time fail, 4 = Cold Sagging Fail (temp dropped during a copy run)
50-21	Plain Paper default weight	0-1	0	0=thicker than 70gsm, 1=70gsm or less
50-7	Enable Tray 4	0-1	1	0=disable Tray 4, 1=Enable Tray 4
53-1	Toner empty (for CRUM read)	0-255	0	Not clear how this code is different from code 27-52
53-31	Toner empty state (for CRUM read)	0-255	55	Not clear how this is different from 53-1 or 27-52
53-36	ATC Code (for CRUM read)	0-1	0	
53-38	ATC Judge (for CRUM read)	0-1	0	
53-39	CRU New or Old (for CRUM read)	0-1	0	0=New, 1=Old

. Now for some Input Component Codes... these are for testing sensors, switches, and such. For some reason, some of the tests are singled out and accessible by choosing "A/D Check", while others are accessed by choosing "IO Check". First, here are the codes available from "A/D Check". You choose "A/D Check" from the "Chain-Function" menu, then enter the test code you want to run. The values which you read with these codes are going to have little meaning unless you have another machine handy which is behaving itself to compare results with.

Here's a list:

Chain-Func	Name	Values (range)	Remarks
7-1	Tray1 Size Sensor	0-1023	Current Tray 1 Size Auto Detect value
7-2	Tray 2 Size Sensor	0-1023	Current Tray 2 Size Auto Detect value
7-3	Tray 3 Size Sensor	0-1023	Current Tray 3 Size Auto Detect value
7-4	Tray 4 Size Sensor	0-1023	Current Tray 4 Size Auto Detect value
7-6	MSI Size Sensor	0-1023	Current MSI Size Auto Detect value
9-30	BTR Monitor (voltage input)	0-1023	

10-20	Fuser Thermistor (control sensor)	0-1023	Standby fuser temperature monitor
15-60	Temperature Sensor	140-710	This sensor is in the machine's body, not in the fuser
15-61	Humidity Sensor	36-400	
15-62	ATC Sensor	200-800	

The rest of the Component Control codes and “Special Tests” are accessed by choosing “IO Check” from the “Chain-Function” menu. Enter the code of the component you want to check or activate. For Input Component Codes (switches, & sensors), when you press ‘Start’, the machine will read the component’s state at that moment and display it on the control console (H for High, L for Low). The state will not change on the display automatically as the state of the component changes... you would have to hit ‘Start’ again to read the sensor again. For output components (motors, solenoids, clutches, etc), the component will activate for a period of time whenever you hit ‘Start’.

Chain-Func	Name	Notes	Test Type
4-1 *	Main Motor	The following voltages will be turned on simultaneous along with the Main Motor: Bias Charge Roll AC, Bias Charge Roll DC, Developer DC, and Bias Transfer Roll output. *	Output
4-2	Fuser Fan Motor (high speed)		Output
6-15	ROS (Laser Unit) Motor		Output
7-19	Tray 2 Lift Motor (feed motor reverse)	Turns on Lift Motor when Tray 2 lift sensor reads "L" (low). Motor stays still if lift sensor reads "H" (high).	Output
7-20	Tray 3 Lift Motor (feed motor reverse)	Turns on Lift Motor when Tray 3 lift sensor reads "L" (low). Motor stays still if lift sensor reads "H" (high).	Output
7-21	Tray 4 Lift Motor (feed motor reverse)	Turns on Lift Motor when Tray 4 lift sensor reads "L" (low). Motor stays still if lift sensor reads "H" (high)	Output
8-2	Takeaway Motor		Output
8-12	Tray 1 Feed Motor Clutch		Output
8-13	Tray 2 Feed Motor Clutch		Output
8-14	Tray 3 Feed Motor Clutch		Output
8-15	Tray 4 Feed Motor Clutch		Output
8-17	SMH Feed Clutch	The acronym list in the manual isn't saying what SMH stands for.. Best guess: Special Media Handler (envelopes, etc).	Output
8-18	Two Tray Module Takeaway Clutch		Output
8-24	Single Tray Module Takeaway Clutch		Output
8-38	Up Motor		Output
8-44	Tray 3 Feed Motor		Output
8-45	Tray 4 Feed Motor		Output
8-46	Single Tray Module Takeaway Motor		Output
8-50	Up Motor	Rotates for sending paper out to registration	Output
9-23	Bias Charge Roll AC Bias		Output
9-24	Bias Charge Roll DC Bias		Output
9-29	Bias Transfer Roll (+) Bias		Output
9-33	Developer DC Bias		Output



9-36	Bias Transfer Roll (-)		Output
10-3	Oscillating Catch Tray Home Check		Output
10-4	Fuser Fan Motor (high speed)		Output
10-5	Oscillating Catch Tray Return & Pre-offset move		Output
10-8	Exit Drive Motor, Forward		Output
10-9	Exit Drive Motor, Reverse		Output
10-10	Exit Motor		Output
10-51	Exit Gate Solenoid		Output
10-61	Offset Motor 1 Center		Output
10-62	Offset Motor 1 Forward		Output
10-63	Offset Motor 1 Reverse		Output
15-63	Dispense Motor		Output
1-1	Left Cover Interlock Switch	L = Cover open / switch off	Input
1-10	Tray Module Cover Interlock Switch	L = Cover open / switch off	Input
1-11	Lefthand Lower Cover Interlock Switch	H = Cover open / switch off	Input
1-12	Front Cover Interlock Switch	L = Cover open / switch off... Note that if the Left Cover is open	Input
7-5	Tray 4 Size Sensor		Input
7-7	Tray 1 Paper Empty Sensor	L = No Paper	Input
7-8	Tray 2 Paper Empty Sensor	L = No Paper	Input
7-9	Tray 3 Paper Empty Sensor	L = No Paper	Input
7-10	Tray 4 Paper Empty Sensor	L = No Paper	Input
7-12	Special Media Handler (SMH) / Envelope Paper Empty Sensor	L = No Paper	Input
7-14	Tray 2 Lift Sensor (stack height sensor)	L = Tray sensed in Up Position	Input
7-15	Tray 3 Lift Sensor (stack height sensor)	L = Tray sensed in Up Position	Input
7-16	Tray 4 Lift Sensor (stack height sensor)	L = Tray sensed in Up Position	Input
7-26	Tray 1 Size Sensor		Input
7-27	Tray 2 Size Sensor		Input
7-28	Tray 3 Size Sensor		Input
8-5	Registration Sensor	L = Paper Detected	Input
8-6	Feed out #2 Sensor	L = Paper Detected	Input
8-8	Takeaway Feed Out Sensor #3	L = Paper Detected	Input
8-9	Takeaway Feed Out Sensor #4	L = Paper Detected	Input
8-31	Duplex Wait Sensor	L = Paper Detected	Input
8-32	Duplex Registration Sensor	H = Paper Detected	Input
8-33	Duplex Interlock Switch	H = Duplex Open	Input
8-35	Registration Clutch	L = Clutch is on	Input
8-47	Feed Ready Signal	H = level is high	Input
8-48	Takeaway Feed Output #3 Sensor	L = Paper Detected	Input
8-49	Takeaway Feed Output #4 Sensor	L = Paper Detected	Input
9-2	Drum Cartridge Detect	L = Cartridge Detected	Input
10-11	Oscillating Catch Tray (OCT) Home Position Sensor	OCT1 is at its home position	Input
10-23	Exit Sensor	L = Paper Detected	Input
20-5	Manual Paper Tray (MPT) Side Guide-Set Minimum Position	Put the Side Guide to minimum size and execute to set the minimum position in memory	Special

20-6	Manual Paper Tray (MPT) Side Guide-Set Maximum Position	Put the Side Guide to maximum size and execute to set the minimum position in memory	Special
20-58	MCU NVM (Non Volatile Memory)	Resets the Main Controller Unit's Memory to defaults	Special
23-10	Test Print	Prints a test pattern (default pattern is bands)	Special
23-13	Tone Up		Special
23-14	Tone Down		Special
43-1	Automatic Toner Control (ATC) Check	The machine reads the ATC sensor and stores a target value, an output value and a decision.	Special

\* For some reason, there are several codes listed for the “Main Motor” including 4-1, 8-1, 9-1, 10-1. The Service Manual does not explain the differences.

That just about does it for the C118 style. Next month, we’ll take a look at the C123 style machines (C123, C128, C133, M123, M128, M133, Pro123, Pro128, Pro133) which look very similar at first glance and actually share the same part number for the Drum Cartridge. As it turns out, they are actually quite different, particularly when it comes to status codes and diagnostics. The word on the street is that the C123 style is actually a very good solid bunch of machines, so I’m looking forward to meeting them.

*Britt works for The Parts Drop, a company whose primary business is providing parts, supplies and information for Xerox brand copiers, printers and fax machines. You can find more information, including many of Britt’s past ENX articles on their website, [www.partsdrop.com](http://www.partsdrop.com). If you’d like to read more about Xerox brand office equipment, there’s also a complete listing of past articles under contributing writers on the ENX website ([www.ENXMAG.com](http://www.ENXMAG.com)).*